

# SolarEdge Power Optimizers Inter-Compatibility

## **Version History**

- Version 9 (Nov 2021) added S440, S500 and S500B.
- Version 8 (Aug 2021) marked P400 and P401 as being inter-compatible.
- Version 7 (May 2021) added P375, P601, P605, P960, P1100. Re-added P300, P600, P700.
- Version 6 (Sept. 2020) marked P950 as compatible with P850 and P800p.
- Version 5 (June 2020) added P320, P340, P370T, P395, P400, OP400-EV,OP-480, P401, P485, P700, P801, P850, P860, P950 OP300-LV, OP350-LV, OP350-MV, OP600-96.Deleted P300, P600, P700.
  - Added remark about M2640 and M1600.
  - Merged Europe and APAC and NAM to a single document.

This technical note specifies inter-compatibility between various models of the S-Series and P-Series SolarEdge power optimizers, as well as the inter-compatibility of the P-Series power optimizers with previous series of power optimizers (PBxxx and OPxxx).

The term "inter-compatibility" refers exclusively to the installation of power optimizers in the same PV string.

When replacing a power optimizer, the replacement power optimizer does not need to be identical to the replaced power optimizer, but it must be compatible with the other power optimizers in the string.



#### NOTE

Installing different series and models of power optimizers in the same installation is allowed as long as they are installed in separate PV strings. However, power optimizers that are inter-compatible may be installed in the same PV string.



#### NOTE

When replacing a power optimizer always verify with the SolarEdge Designer that the power, current and voltage specifications of the PV module are compatible with the replacement power optimizer specifications. Ensure that the module Voc (at minimum ambient temperature) does not exceed the replacement power optimizer's maximum input voltage. Use the SolarEdge Designer to quickly validate electrical compatibility.

Refer to the power optimizer datasheet for details.



The following compatibility tables detail the Power Optimizer series and models that can be installed in the same PV string, during installation or in case a power optimizer is being replaced.

If a cell does not contain a check mark, the relevant power optimizers cannot be installed in the same string.

Table 1: S-Series Power Optimizer Inter-compatibility

		S440	S500	S500B
	S440	<b>✓</b>	<b>✓</b>	
S-Series	S500	<b>✓</b>	<b>✓</b>	
	S500B			<b>✓</b>
P-Series	P401	<b>✓</b>	<b>✓</b>	
P-Series	P505			✓

#### Remarks:

The general recommendation is to avoid installing P-Series and S-Series Power Optimizers in the same PV string. If this is unavoidable:

- Any P-Series Power Optimizer that is compatible with the P401 Power Optimizer is also compatible with the S440 and S500 Power Optimizers.
- Any P-Series Power Optimizer that is compatible with the P505 Power Optimizer is also compatible with the S500B Power Optimizer. See, Table 2: P-Series Power Optimizer Inter-compatibility, on page 3.
- When replacing P-Series Power Optimizers with S-Series Power Optimizers verify that the inverter firmware version is updated as follows:
- For inverters with LCDs minimum required version 3.2537.
- For SetApp enabled inverters minimum required version 4.8.xx.



#### NOTE

Installing P-series and S-series Power Optimizers on the same PV string requires the use of an extension cable. For more details refer to the <u>Using Extension and Adapter cables</u> with <u>Power Optimizers</u> application note.



Table 2: P-Series Power Optimizer Inter-compatibility

		P300	P320	P340	P350	P370	P370T	P375	P395	P400	P401	P404	P405	P485	P500	P505	P600	P601	P605	P650	P700	P701	P730	P800p**	P801	P850	P860	P950	P960	P1100
																								1 222		***				
	P300	~	~	<b>✓</b>	<b>✓</b>	~		<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>				<b>✓</b>															
	P320	✓	<b>✓</b>	✓	<b>✓</b>	✓		✓	✓	✓	✓				✓															
	P340	<b>✓</b>	~	✓	~	✓		~	~	~	~				✓															
	P350	<b>✓</b>	<b>✓</b>	✓	<b>✓</b>	✓		✓	✓	✓	✓				✓															
	P370	✓	✓	✓	✓	✓		<b>✓</b>	✓	✓	✓				✓															
	P370T						✓																							
	P375	<b>✓</b>	<b>✓</b>	<b>✓</b>	✓	<b>✓</b>		<b>✓</b>	<b>✓</b>	✓	<b>✓</b>				<b>✓</b>															
	P395	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>		~	~		~				<b>✓</b>															
	P400	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>		<b>✓</b>		<b>✓</b>	<b>✓</b>				<b>✓</b>															
	P401	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>		<b>✓</b>	✓	<b>✓</b>	✓				<b>✓</b>															
P-Series	P404											✓	✓	✓		✓		<b>✓</b>												
	P405 **											✓	✓	✓		✓		<b>✓</b>												
	P485											✓	✓	✓		✓		<b>✓</b>												
	P500	~	✓	✓	✓	✓		<b>✓</b>	✓	✓	✓				✓															
	P505											<b>✓</b>	✓	<b>✓</b>		✓		<b>✓</b>												
	P600																✓			✓	<b>✓</b>	<b>✓</b>	✓		<b>✓</b>					
	P601											<b>✓</b>	<b>✓</b>	<b>✓</b>		<b>✓</b>		✓												
	P605																		✓											
	P650																<b>✓</b>			<b>✓</b>	<b>V</b>	<b>✓</b>	<b>✓</b>		<b>V</b>					
	P700																<b>✓</b>			<b>✓</b>	<b>V</b>	<b>√</b>	<b>✓</b>		<b>V</b>					
	P701																<b>✓</b>			<b>✓</b>	<b>V</b>	<b>√</b>	<b>✓</b>		✓ ✓					
	P730																<b>✓</b>			<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>		~			<b>✓</b>		<b>✓</b>
	P800p **																<b>✓</b>			<b>✓</b>	<b>/</b>	<b>✓</b>	<b>/</b>	<b>✓</b>	<b>/</b>	<b>✓</b>		•	<b>✓</b>	<b>v</b>
	P801																•			•	· •		-	_	~	<b>✓</b>		<b>✓</b>	<b>✓</b>	<b>✓</b>
	P850 ***																							· ·		~	<b>✓</b>	•	•	_
	P860																							<b>/</b>		<b>✓</b>	•	<b>✓</b>	<b>✓</b>	<b>✓</b>
	P950											1											1	· ·		✓ ✓		·	<b>✓</b>	<b>▼</b>
	P960																				-			· ·	-	<b>∨</b>		·	<b>✓</b>	<b>✓</b>
	P1100		<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>		<b>/</b>							<b>/</b>						-				-	ŀ		-	-	_
	OP250-LV		<b>✓</b>	<b>✓</b>	·	<b>✓</b>		·							<b>✓</b>															
	OP300-LV OP300-MV		<b>✓</b>	<b>V</b>	· /	·		·		<b>✓</b>					· /															
	OP300-MV OP350-LV		<b>✓</b>	· /	· /	·		<b>✓</b>	<b>✓</b>	✓	<b>✓</b>				· /															
	OP350-LV OP350-MV		·	· /	· /	·		<b>✓</b>		✓					· /															
	UP350-IVIV			•													1	1	1		1	1			1		1	1		



		P300	P320	P340	P350	P370	P370T	P375	P395	P400	P401	P404	P405	P485	P500	P505	P600	P601	P605	P650	P700	P701	P730	P800p**		P850	P860	P950	P960	P1100
																										***				
	OP400-MV		<b>✓</b>	~	<b>✓</b>	<b>✓</b>		~		~					✓															
OP-Series	OP400-EV		~	~	~	<b>✓</b>		<b>✓</b>		~					<b>✓</b>															
	OP480		<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>		<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>				<b>✓</b>															
	OP500-IV														<b>✓</b>															
	OP600-96																✓			<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>		~					
PB-Series	PB250-AOB		<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>		<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>				<b>✓</b>															
	PB350-AOB		<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>		>	<b>✓</b>	<b>✓</b>	<b>✓</b>				>															
	PB350-TFI		~	~	~	<b>✓</b>		<b>✓</b>	~	~	~				<b>✓</b>															
Module	OP250-LV		<b>~</b>	~	~	<b>✓</b>		<b>✓</b>	~	~	~				<b>✓</b>															
Embedded																														
	PB250-CSI		~	~	<b>✓</b>	<b>✓</b>		<b>✓</b>	<b>✓</b>	~																				
	OPJ300-LV		~	~	~	<b>✓</b>		<b>✓</b>	~	~	~				<b>✓</b>															

### Remarks:

M series power optimizers (M2640 and M1600); cannot be used interchangeably and cannot be connected with any other power optimizer in the same string.

<sup>\*\*</sup> For P405, P485 and P800p, the same replacement options apply for both the single and dual input versions.

<sup>\*\*\*</sup> P850 replaced P800s; They can be used interchangeably and can be connected in the same string.