

# m.ginlong.com Monitoring Guide

# Contents

1.	Soli	Solis Second Generation monitoring platform for installers						
2.	Reg	Register an installer account						
3.	Usi	ng the installer account	3					
	3.1.	Logging in	3					
	3.2.	Creating a plant	3					
	3.3.	Associate end-customer to the plant	5					
	3.4.	Adding device to the plant	6					
	3.5.	Testing the system	8					
	3.6.	Monitoring the system	8					
	3.7.	Adding device to the plant	8					

## 1. Solis Second Generation monitoring platform for installers

This serves as a guide to help installers create and use their Solis remote monitoring account. Most of the accounts from our old platform (www.ginlongmonitoring.com) have been moved successfully to this new platform.

2. Register an installer account

Open your browser (preferably Google Chrome)

Type in the top bar <u>http://m.ginlong.com/login.html</u> and press enter.

This will take you to our login page for end-customers (seen below in Figure 1: login page for m.ginlong.com).

偉 Login - PV Monitoring × +			- a ×
← → C A Not secure   m.ginlong.com/login.html			•• @ ☆ <b>0</b> :
Platform 2.0 login guide   APP Download		中文 English Português Polski   Login	
		-	
	Switch to Professiona	al )	
		_	
	<b>B</b>		
	Login Register		
	Email or Phone Number		
	Password 🥠		
	Login		
			Custor
	Auto Login Next Time Login Problem		Servio
			6
	Version V2.1.5.2		
	Chrome58, Firefox49, QQ 9, 360 8, Sogou 7, Edge 38 Broswers Recommended		

Figure 1: login page for m.ginlong.com

To move to our installer login page, press "Switch to Professional"

Then click on the "Free Application" button (seen below in Figure 2: Installer login page) on the top right to take you to our installer registration page.

住 Login - Professional × +		- 8 ×
← → C A Not secure   m.ginlong.com/login.html		॰ @ ☆ 🖰 :
Platform 2.0 login guide APP Download	中文 English Português Polski Free Application   Login	
	Switch to PV Monitoring	
	Patiente and a second sec	
	2	
	CR	
	Email or Phone Number	
	Password Ø	
	Password	
	Login	
	Login	
	Auto Login Next Time Login Problem	
		Custor Servio
		Custor Servic
	Version V1.6.15 Chrome58, Firefox49, QQ 9, 360 8, Sogou 7, Edge	

Figure 2: Installer login page

Follow the registration steps and click complete, the account will be verified within 3 business days.

### 3. Using the installer account

The following will guide the reader through the process of plant (an end-customer PV site or installation) setup and the process of associating (linking or assigning) end-customers to see their relevant plants.

#### 3.1. Logging in

We have two different applications for this monitoring platform: Ginlong Home, for end users; and Ginlong Pro, for installers and distributors. They work on both android and iOS platforms and can be downloaded at GooglePlay (<u>https://play.google.com/store/apps/developer?id=Ginlong&hl=en\_GB</u>) and the other place no one really wants to use.

#### 3.2. Creating a plant

The first thing you need to do to get started is create a plant. This is done by hovering your mouse over the "Plant Centre" button and then clicking on "Create new Plant" (as shown below in Figure 3: Create new plant).

년 Plant Center - Professional	× +	- o ×
$\leftrightarrow$ $\rightarrow$ C (i) Not secure	m.ginlong.com/main.html	९ ☆ 🛛 :
CH.	Plant Center Device Center Alert Center Report Center Work List Center Search plant, device Q	paul
«	Create New glect Management > Project Overview > Status ~ Region ~ Plant Type ~ Capacity ~ Plant Name : None ~ Clear Set the visible field	d Create New Plant
<ul> <li>Project Management</li> </ul>	Real-time	
:: Project Overview	Operating Status Updated by : 2018-11-05 11:43 C Generation Overview Updated by : 2018-11-05 11:43 C Within an Hour Alert	
2 Project Diagrams	Normal     Offline       0     O       Total Plants     Alert       0     O       0     O       0     O       0     O       0     O       0     O       0     O       0     O       0     O         0         0         0         0         0         0         0 <t< th=""><th>s-11-05 11:43</th></t<>	s-11-05 11:43
	List Mode	
	Status Name / Locati Plant Type Capacity 🗘 Owner Info Power 💠 Daily Generati. Daily Trends Today's latest Last Updated ᡇ Operation	Custo
	T_T	
	No Data	
12:48:30 2018-11-05 Monday (JTC+01:00) Version : V1.6.15	Select All	Correlate All

Figure 3: Create new plant

Complete the form with the relevant details of the plant then click Next. Where it asks you "Gridconnected Type" for PV inverters select "Distributed All Power on Grid" and for Hybrid inverters select "Storage System" (seen below in Figure 4: Grid-connected Type).

Plant Name	Paul's First Site				
Plant Type	<ul> <li>Residential Roof</li> <li>Commercial Roof</li> <li>Industrial Roof</li> <li>Surface Power Station</li> </ul>				
Grid-connected Type	<ul> <li>Distributed All Power on Grid</li> <li>Partly On-grid</li> <li>Off-grid</li> <li>Storage System</li> <li>Full ground Internet</li> </ul>				

Figure 4: Grid-connected Type

#### 3.3. Associate end-customer to the plant

At this point we are given the opportunity to add Associations (end-customers that will be able to see the plant). You have the following options in doing so.

년 Plant Center - Professional	× +									- 0 ×
← → C ▲ Not secure	m.ginlong.com/main.h	html								@☆ 🖰 :
UK.	Plant Center	Device Center	Alert Center	Report Center	Work List	Center		Search plant、device	Q	paul
«	Plant Center > P	Project Management ≻	Create New Plant							
: Project Overview										
2 Project Diagrams					Confirm Plan Description Internal Association User Founder		Co or click to select	nfirm Correlation Info		
					Owner	Back Create a PV Mo	What Is Owner?	r		Custe Servi

Figure 5: Owner dropdown bar

#### Option 1: the simplest

The easiest way to do this is to choose the "Create a PV Monitoring ID for Owner" option by hovering your mouse over the Owner drop down bar (as seen above in Figure 5: Owner dropdown bar). This creates an end-user account for the customer with their email address and a default password of "123456". This is a basic password and the account will have no control over the plant so it is safe to have such an insecure password, however the installer account password should be secure.

#### Option 2: don't have customer details

If you do not want to associate the end-customer at this stage just select "I am Owner" and you will be the only one that will be able to see this plant, until you add an end-customer. You can add an end-customer at a later by clicking on the "Association Relations" button (shown below in Figure 6: Association Relations button) on the plant overview screen (accessed by clicking "Plant Center" on the top left).

	s + Angliong.com/main.html	– □ × 0 ☆ ⊖ ::
C.K.	Plant Center Device Center Alert Center Report Center Work List Center Search plant, device Q	paul
«	Plant Center > Project Management > Project Overview > Status >       Region >       Plant Type >       Capacity >       Plant Name : None >       Clear       Set the visible field	Create New Plant
	Real-time	
Project Overview           Project Diagrams	Operating Status Updated by: 2018-11-05 12:16 C Generation Overview Updated by: 2018-11-05 12:16 Vithin an Hour Alert Updated by: 2018-11-05 12:16 Updated by: 2018-11-05 Updated by: 2	05 12:16 📿 >
	Normal     Offline       1     O       1     Alert       Building       0     1         Image: Current Power       SkWp       SkWp       Site Capacity         Daily Generation       Monthly Generation       Okwh	Fault O
	List Mode	
	Status Name / Locati Plant Type Capacity 💠 Owner Info Power 💠 Daily Generati. Daily Trends Today's latest Last Updated 🌲 Operation	Se
	Paul's First Site     Residential     SkWp     PaulCarpenter      12:01       Q China/Jangs     Poul's First Site     PaulCarpenter       2018-11-05	
	View: 20 🗸 < < 1 > > 1 / 1Page 1Result(s)	

Figure 6: Association Relations button

#### Option 3: end-customer already made an account

If the end-customer already has an account (they have multiple plants for example) you can select "Correlate Owner's PV Monitoring ID (recommended)" and put in their ID to associate them to the plant. The end-customer can find their ID by logging into their account and looking at the top left (seen below in Figure 7: Finding PV-owner's ID).

住 Plant - PV Monitoring x +						
← → C ③ Not secure   m.ginlong.com/main.html	l.				९ ☆ 😬 :	
		Plant		Paul0 D:278574		
Waiting for m.ginlong.com						
warang tor mightiong.com						

Figure 7: Finding PV-owner's ID

#### 3.4. Adding device to the plant

You are also given the opportunity to add devices upon creation of the plant, however again you are not restricted to doing so (as shown below in Figure 8: add device now).




Figure 8: add device now

Adding a device is as simple as getting the serial number of the datalogger (**not the inverter**) and putting in the relevant box (as shown below in Figure 9: adding a device). You can add multiple dataloggers (inverters) to a single plant.

If you get the warning message "The SN number has already been registered to other plants", this means exactly what it is telling you. Someone has already assigned this datalogger to their plant. In the case that this is in fact your serial number and do not know why you are getting this message, email your local support team to sort it out.

Plant Center - Professional - → C ▲ Not secure	× + m.ginlong.com/main.h	ıtml										- ¤ 0. ☆ <b>0</b>
UK NANT	Plant Center	Device Center	Alert Center	Report Center \	Work Lis	st Center	Sear	ch plant、device		Q		paul
«	Plant Center Proj	iect Management Proj	ect Overview Paul's	First Site >						Add New Device	Plant Sett	ings Delete Plan
<ul> <li>Project Management</li> </ul>	Details	Plant Details	vlodule Layout	Device Alert								
Project Overview	Inverter D	ata Logger Microi	nverter Modul	le Weather Station	Meter	Battery Power						
Z Project Diagrams	Device Sta N	Jame / SN Brand	Curren	t Generatio Daily Gene	eration	Logger Status Connected	Commu	nication Sigr	al Strength Ba	lance Latest Alerts	Last Up	dated 💠 Operation
						Add New Device			×			
				c	Device Type	Data Logger	~ (?	)	- 1			
						SOLARMAN	~		- 1			
									_			
					Ļ	7007 de202serial number goes here The SN number has already been registered to other plants	Ad	d Import	_			
				SN		· ·	eration		_			
2.15.42												
1 <b>3:15:43</b> 018-11-05 Monday												
UTC+01:00)												
Version : V1.6.15												

Figure 9: adding a device

#### 3.5. Testing the system

If the datalogger has an internet connection and you have added it correctly you should be able to see the data being sent to the plant, you have just created.

It is also a good idea to login with the PV Owner's account and check if they can see the plant too.

#### 3.6. Editing the plants

If you log back into your installer account on the "Professional" login page, you will now see all the plants you have ever created (seen below in Figure 10: Multiple plants on installer account).

To add a new datalogger simply click the "Device" button and on the top right of the page click the "Add new Device" button.

∉ Plant Center - Professional     ↔ → C ▲ Not secure	+ n.ginlong.com/main.html			– ठ× ९ ४ <del>0</del> :
UK.	Plant Center Device Center Alert Center R	eport Center Work List Center	Search plant、device	Q 🛛 🙆 paul
«	Plant Center > Project Management > Project Overview > S	atus 🗸 Region 🗸 Plant Type 🗸 Capacity 🗸	Plant Name : None V	Set the visible field Create New Plant
<ul> <li>Project Management</li> </ul>	Real-time			
Project Overview	Operating Status Updated by : 2018-11-05 14:26 3 Normal Offline 0 0 Alert Building 0 2	Generation Overview Daily Generation Okwh Current Power I0kWp Okwh Okwh	ion Monthly Generation Okwh	Aithin an Hour Alert Updated by : 2018-11-05 14:26 C > O Alerts O O O
	List Mode	Site Capacity UkWh	• • • • • • • • • • • • • • • • • • •	d ‡ Operation
	Paul's First Site     Q ChinaJiangs     Residential SkWp	PaulCarpenter		Device Association Relations Edit Delete
45.07.00	Paul's Second 9 ChinaJiangs Residential 5kWp	PaulCarpenter	14:26 2018-11-05	Device Association Relations Edit Delete
15:27:02 2018-11-05 Monday		View: 20 🗸 🔍 🔹 🕇	> 1 / 1Page 2Result(s)	
(UTC+01:00) Version : V1.6.15	Select All			Correlate All

Figure 10: Multiple plants on installer account

#### 3.7. Monitoring the plants

When you are in "Plant Center" you can see the total energy for all your plants and if you click on an individual plant you will see the data only for that plant (as seen below in Figure 11: Plant overview).

<ul> <li>Project Management</li> </ul>	Details Plant Deta	ails Module Layout Device	Alert							
Project Overview	Real-time									
🛛 Project Diagrams	Electricity gen eration	Power 64.37w	Daily Average Peak-hours 2.07							
		Daily Generation 1.60kWh	Monthly Generation 14.90kWh	Annual Generation 2.40MWh	Total Generation 9.09MWh	٥				
	්	Daily Revenue 0.35GBP	Monthly Revenue 3.23GBP	Annual Revenue 305.68GBP	Total Revenue 1999.8GBP	0				
	< 2018/11/05 >	Export detailed data					Day Month	Year Total		
	Daily Generation: 1.60kWh									
	kW		Select Paramet v							
	1			٢	1					
22.40.20	0		~		hay					
22:48:28 2018-11-05 Monday (UTC+08:00) Version : V1.6.15	00:00	03:00	06:00 0	9:00 12:00	15:00	18:00	21:00			

Figure 11: Plant overview

If you click on the left side of the screen "Project Diagrams" it is a perfect local display screen (as seen below in ). You can also change the graph to display the data in day/month/year.

If you click on the "Device" button you can see data in more depth (shown below in Figure 12: Traces for multiple parameters). You can click on the "Select Parameter" dropdown box to select what parameters you want to see. This is extremely useful for troubleshooting inverters.




Figure 12: Traces for multiple parameters